

Installation Advice for Tubolit tubes

1. The surface has to be clean, dust and fibre free.
2. Ideal working temperature: +10°C to +35°C
3. Pull tube open and place around the pipe
4. Apply Armaflex adhesive to the two edges with a thin even film of adhesive using a short bristle brush. Apply the adhesive at 200mm intervals , along the tube length.

Alternatively Tubolit clips may be used to close the seam.

Always position longitudinal seam to the side.

5. On curved sections tubing should be cut into segments.
Use Adhesive 520 and wrap around the pipe. Cover both ends of the curve with Tubolit Tape.

